



P77.39-2085-09

Shown on model 209.4

- 1 Partition net
- 2 Bolts (model 209.4)
- 3 Nuts

- 4 Bracket
- 5 Electrical connector
- 6 Screw

- S84/9 Variable soft top compartment limit switch

	Remove/install		
Danger!	Risk of injury when performing check and repair work in area of roll bar	Before working in the area of the roll bar, pull out the rear head restraints by hand. Keep body parts out of the area where the roll bar extends.	AS91.00-Z-0003-01QA
Danger!	Risk of injury caused by moving parts that can pinch, crush or, in extreme cases, even sever extremities	No parts of the body or limbs should be within the operating range of the mechanism when moving components.	AS00.00-Z-0009-01A
Danger!	Risk of injury caused by scraping or cutting body parts on sharp vehicle parts	Always wear protective gloves when working on or near sharp and non-deburred vehicle parts. Deburr repair panels.	AS00.00-Z-0017-01A
1	Partially open soft top	Leave soft top bow and soft top compartment cover in upright position	
2	Cover vehicle in left rear area	To prevent scratching the paint during assembly work.	
3	Unhook partition net (1)		
4	Move trunk luggage cover to upper position	Model 207.4	
5	Pull bolts (2) out of bracket (4)	Model 209.4 Installation: Replace bolt (2).	
6	Disconnect electrical connector (5) from variable soft top compartment limit switch (S84/9)		
7	Unscrew nuts (3) from bracket (4)	Model 209.4	*BA68.50-P-1001-01A
8.1	Pivot bracket (4) with variable soft top compartment limit switch (S84/9) toward front	Model 207.4	
8.2	Remove bracket (4) with variable soft top compartment limit switch (S84/9)	Model 209.4	
9	Unscrew bolt (6) and remove variable soft top compartment limit switch (S84/9) from bracket (4)	On model 207.4 the variable soft top compartment limit switch (S84/9) is bolted to the bracket (4) with two bolts (6). Installation: Ensure that variable soft top compartment limit switch (S84/9) is seated correctly in bracket (4).	
10	Install in the reverse order		

Nm Curtains/sun shades

Number	Designation	Model 209.4
BA68.50-P-1001-01A	Nut for sun shade mount	Nm 8 (±0.8)