AR91.25-P-1580Q Remove/install the pneumatic pump for dynamic seat control

9.6.06

MODEL 209

with CODE (404) Orthopedic driver seat backrest (multicontour backrest in model 140), left with CODE (405) Orthopedic driver seat backrest (multicontour backrest in model 140), right

Shown on model 209.3


1 Damping material

Electrical connector

2 Pneumatic lines

3

M33 Electric air pump



P91.25-2245-04

Modification notes

23.5.06 "Disconnect/connect ground line on battery" removed		
---	--	--

X	Remove/install		
1 Remove left side tri	Remove left side trim in trunk	Model 209.3	AR68.30-P-4600PB
		Model 209.4	AR68.30-P-4600QA
2	Remove electrical air pump (M33) with damping (1) upwards		
3	Remove damping (1) from the electrical air pump (M33)		
4	Remove pneumatic lines (2) from the electrical air pump (M33)	inspect connections of the pneumatic lines (2) for damages.	
5	Disconnect electrical connector (3) from electrical air pump (M33)		
6	Remove electrical air pump (M33) from the luggage compartment		
7	Install in the reverse order		
8	Carry out function check		