


**Fuse assignment**

1 to 20    Socket

N10/2    Rear SAM control unit with fuse  
and relay module

P54.15-2206-06

Bay	Fuse	circuit	Connection	Line identification (line fused)	Fused function	Rating in amperes (A)
1	N10/2f1	15R	1, pin 6	-	● Spare	30
2	N10/2f2	15R	1, Pin 5	-	● Spare	30
3	N10/2f3	30	7, Pin 1 9, Pin 1 17, Pin 1 9, Pin 4 16, Pin 1	0.5 RDWH 0,75 RDYE 0.75 RDGN - RDGN 0.5	<b>Valid for code (475) tire pressure monitor:</b> <ul style="list-style-type: none"><li>TPM [RDK] control unit (N88) (up to 31.5.04)</li></ul> <b>Valid for <sup>(USA)</sup> with code (860) TV tuner:</b> <ul style="list-style-type: none"><li>TV tuner (A2/42) (up to 31.5.04)</li><li>TV tuner (MOST) (A2/10) (as of 1.6.04)</li><li>Rear dome lamp (E15/3)</li><li>Spare</li></ul> <b>Valid for code (228) stationary heater:</b> <ul style="list-style-type: none"><li>STH radio remote control receiver (A6/1)</li></ul>	7.5
4	N10/2f4	30	1, Pin 3	2,5 BKGN	● Fuel pump (FP) (M3) (up to 31.5.04) ● Fuel pump (FP) (M3) (as of 1.6.04)	15 20
5	N10/2f5	30	-	-	● Spare relay 2 (N10/2kC)	20
6	N10/2f6	30	28, Pin 1	1.5 RDBU	<b>Valid for code (889) Keyless Go:</b> <ul style="list-style-type: none"><li>Keyless Go rear module control unit (N102)</li></ul>	20
7	N10/2f7	15R	-	-	● Backup relay 1 (N10/2kD)	20
8	N10/2f8	30	23, Pin 4 4, pin 4 4, Pin 5	0,5 RDYE 0,75 RDYE 0,5 RDBU 0,5 RDWH	● Window antenna amplifier module 1 (A2/71) (up to 31.5.04) ● Amplifier module 2 window antenna (A2/72) (as of 1.6.04) <b>Valid for code (551) Anti-theft alarm system (ATA [EDW]):</b> <ul style="list-style-type: none"><li>Alarm horn (H3)</li><li>ATA [EDW] inclination sensor (B33) (not <sup>(USA)</sup>, <sup>(J)</sup> as of 1.6.06)</li></ul>	7.5
9	N10/2f9	30	22, Pin 4	2,5 RDBU	● Overhead control panel control unit (N70)	25
10	N10/2f10	15R	20, Pin 5	2,5 BK	● Heated rear window (R1)	40
11	N10/2f11	30	20, Pin 3	-	● Spare	20
12	N10/2f12	15R	20, Pin 2	1,5 RDBU	<b>Valid for <sup>(USA)</sup> as of 1.6.04:</b> <ul style="list-style-type: none"><li>Power outlet (X58/27)</li></ul>	15
13	N10/2f13	15R	19, Pin 1	0,75 BKYE	<b>Valid for code (404) Left multicontour seat:</b> <ul style="list-style-type: none"><li>Multicontour seat pneumatic pump (M40)</li></ul>	5

			5, Pin 2	0,5 BKYE 0,5 BKYE 0,75 BKYE	<b>Valid for <small>USA</small> with Motorola Star TAC portable CTEL, retrofitting:</b> <ul style="list-style-type: none"><li>Telephone interface (A34/4)</li></ul> <b>Valid for code (813) voice control system (VCS [SBS]):</b> <ul style="list-style-type: none"><li>Voice control system control unit (A35/11) (up to 31.5.04)</li></ul> <b>Valid for <small>J</small> as of 1.6.04:</b> <ul style="list-style-type: none"><li>VICS+ETC voltage supply separation point (X137/1)</li></ul> <b>Valid for code (220) Parktronic system (PTS):</b> <ul style="list-style-type: none"><li>PTS control unit (N62)</li></ul>	
14	N10/2f14		-	-	-	-
15	N10/2f15	30	-	-	<ul style="list-style-type: none"><li>Fuel filler cap polarity reverser relay 1 (N10/2kG)</li><li>Fuel filler cap polarity reverser relay 2 (N10/2kH)</li></ul>	7.5
16	N10/2f16	30	5, Pin 1	0,75 RDVT 0,75RDBK 0,75 RDVT 0,5 RDBK 0,75 RDVT 0,75RDBK 0,75RDBK	<b>Valid for <small>USA</small> with Motorola Star TAC portable CTEL, retrofitting:</b> <ul style="list-style-type: none"><li>Telephone interface (A34/4) (up to 31.5.03)</li><li>Telephone interface (A34/4) (as of 1.6.03)</li></ul> <b>Valid for code (813) Voice control system (VCS [SBS]) (up to 31.5.04):</b> <ul style="list-style-type: none"><li>Voice control system control unit (A35/11) (valid for <small>USA</small> up to 31.5.03)</li><li>Voice control system control unit (A35/11) (valid for <small>USA</small> as of 1.6.03)</li><li>Voice control system control unit (A35/11) (except <small>USA</small>)</li></ul> <b>Valid for code (813) voice control system (VCS [SBS]) (as of 1.6.04):</b> <ul style="list-style-type: none"><li>Voice control system control unit (A35/11/)</li></ul> <b>Valid for <small>J</small> as of 1.6.04:</b> <ul style="list-style-type: none"><li>Hands-free system control unit (A35/1)</li><li>VICS+ETC voltage supply separation point (X137/1)</li></ul>	7.5
17	N10/2f17	30	-	RDGN 2.5	<b>Valid for code (550) trailer hitch:</b> <ul style="list-style-type: none"><li>Trailer recognition control unit (N28/1/)</li></ul>	20
18	N10/2f18	30	-	2.5 RDYE	<b>Valid for code (550) trailer hitch:</b> <ul style="list-style-type: none"><li>Trailer hitch socket (13-pin) (X58)</li></ul>	20
19	N10/2f19	30	-	1,5 RDWH	<b>Valid for code (404) Left multicontour seat:</b> <ul style="list-style-type: none"><li>Multicontour seat pneumatic pump (M40)</li></ul>	20
20	N10/2f20	30		0,75 RDBU 0,75 RDBU	<b>Valid for code (540) Electric rear window roller blind:</b> <ul style="list-style-type: none"><li>Rear window roller blind relay (K74)</li></ul> <b>Valid for code (819) CD changer (6CDs):</b> <ul style="list-style-type: none"><li>CD player with changer (in glove compartment) (A2/6) (as of 1.6.04)</li></ul>	10