



- A1 Instrument cluster
 N3/10 ME-SFI [ME] control module
 N15/5 Electronic selector lever control module
 N26/5 Electric steering lock control module
 N69/8 Left door keyless go control module
 N69/9 Right door keyless go control module
 N73 DI control module
 N102 Rear module Keyless Go control module
 N103 Interior module Keyless Go control module



P80.61-2091-11



P80.61-2119-09

- A2/31 Rear bumper antenna
 A2/35 Keyless go antenna, trunk
 A2/38 Left door keyless go antenna
 A2/40 Right door keyless go antenna
 A8/1 Transmitter key

- M57 Left opening assist motor
 M57/1 Right opening assist motor
 S2/3 Keyless go start and stop button
 S17/19 Left door handle switch

- S17/21 Right door handle switch
 S62/21 Trunk lid keyless go button
 Z87/15 Keyless Go RF antenna cable end